




Console Module

XP0020




Quick Start Guide (V1.0)



Packing List

The following items are included in your package. If you find anything missing, contact your system administrator.



Console Module



Stand




Spiral Shell



Connecting Cord




Connecting Sheet




Quick Start Guide &
Quick Reference

Connect to the Phone

1. Use the connecting sheet and spiral shell to connect the console module to the IP phone, as shown below:




The phone and the console module are connected as shown below:




Attach the Stand

2. Attach the stand, as shown below:




Connect to the Next Console Module

3. Use the connecting sheet and spiral shell to connect the next console module, as shown below:




The phone and the two console modules are connected as shown below:



Note: The IP phone supports up to two console modules. Repeat the steps listed above to connect more console modules.

Connect the Cords

4. Connect the connecting cord between the **Ext** port on the IP phone and the **Ext in** port on the first console module. Connect the connecting cord between the **Ext out** port on the first console module and the Ext in port on the second console module.



Note: Repeat the step to connect the cords for more console modules.

Startup

Power is automatically transferred from the host IP phone to the console modules upon connection. However, if you use more than two console modules, you need to connect an additional power adaptor to any of the console modules.

The console modules automatically begin the loading process after being supplied with power. After that, you can configure key features for them via the Web browser interface or the phone user interface. For more information on how to use your new console module(s), refer to the Quick Reference guide in the package.